



 $\overrightarrow{\oplus}$

2= LOW PROFILE LATCH

2

 \Box

1 l

1= STANDARD LATCH

D

form: A3

PDS: Rev :AB STATUS:Released Printed: Mar 03, 2015

index sheet

sheet

P F08-0146 YOV 08.04.11

revision

R B-16776 LMU 14.01.23 dr

S |B-19092|LMU|14.10.16|engr

T B-20349 BVE 15.03.02 chr

scale 2:1

dwg no

type

5 l

sheet 2 of - size

CUSTOMER Drawing

71922

01.01.24

01.01.24

01.01.24

01.01.24

JM.C

JF.N

appd